

## Behringer FCB1010 – Roland VGA-7

Bank 00 Preset	Description	Prog Chg				CNT 1 No/Value	CNT 2 No/Value	Prog Chg 5	Note	SW 1	SW 2	EXP A No/Range	EXP B No/Range
		1	2	3	4								
1		1										7/00-127	14/01-127
2		2										7/00-127	14/01-127
3		3										7/00-127	14/01-127
4		4										7/00-127	14/01-127
5		5										7/00-127	14/01-127
6		6										7/00-127	14/01-127
7		7										7/00-127	14/01-127
8		8										7/00-127	14/01-127
9		9										7/00-127	14/01-127
0.		10										7/00-127	14/01-127

Note: Bank 00 to 07 setup is similar, only differ in Program Change Number: Bank 01 1 – 0. -> Prog Chg 11-10. ... Bank 07 1 – 0. -> Prog Chg 71-70.  
Bank 08 is left blank.

Bank 09 Preset	Description	Prog Chg				CNT 1 No/Value	CNT 2 No/Value	Prog Chg 5	Note	SW 1	SW 2	EXP A No/Range	EXP B No/Range
		1	2	3	4								
91	USR User, PrgChg5, Patch 1, Volume 0	1				00/0	07/0	1				7/00-127	14/01-127
92	PRE Preset, PrgChg5, Patch 1, Volume 0	2				00/1	07/0	1		On		7/00-127	14/01-127
93	MAN Manual/Memory	3				64/127	64/0					7/00-127	14/01-127
94	CAP Capo On/Off	4				70/127	70/0					7/00-127	14/01-127
95	EFX Effects On/Off	5				65/127	65/0					7/00-127	14/01-127
96	TAP Tap Delay time	6				69/127	69/0					7/00-127	14/01-127
97	DEL Delay On/Off	7				66/127	66/0					7/00-127	14/01-127
98	CHO Chorus On/Off	8				67/127	67/0					7/00-127	14/01-127
99	REV Reverb On/Off	9				68/127	68/0					7/00-127	14/01-127
90.	TUN Tuner On/Off	10				80/127	80/0					7/00-127	14/01-127

Note: On VGA-7 set Omni On and MIDI channels on VGA-7 to 7 for Volume and 14 for WAV  
Press [SYSTEM] -> Power On, Select Parameter 2, 4, 5 – set to Value 'On', '7', '14' ->[SYSTEM] to exit

On FCB1010 set different MIDI channels for CNT1 and CNT 2

[Down] pressed -> Power On, [Up], CNT1, [Up], '1' (MIDI Channel), [Up], CNT2, [Up], '2' (MIDI Channel 2), [Up] - [Down] pressed -> Exit

Preset 92 – The SW 2 is programmed to be of latch type (in global setup) -and just serves as an indicator to tell if Preset is On.